


Dimension Guide

Espresso coffee maker

Model:
E5EC1-31ST

Dimensions

	width	height	depth
Product (mm)	147	304	412



Important! Please ensure that the access to your kitchen (including doorways, corridors, island benches, etc) allows sufficient clearance to move your fridge into position.

Please note! Dimensions to be used as a guide only. All customers MUST refer to the user manual supplied with the product for detailed installation instructions.

© 2022 Electrolux S.E.A PTE. LTD. E_DIM_E5EC1-31ST_Jun22